

# Installation guidance

Gyproc® Joint Filler

## Hand applied jointing

### Step 1



Ensure that boards have been prepared for jointing

### Step 2



Add approx. 6.75 litres of clean water per bag to a clean mixing bucket. Gradually add the powder stirring continuously until a smooth creamy consistency is achieved

Leave to stand for 5 minutes before final mixing

### Step 3



Apply Gyproc Joint Filler to the joint to embed the tape and immediately overcoat to fully fill the tapered board edges

### Step 4



Trowel apply further applications of Gyproc Joint Filler if required allowing each coat to set before the next application

Make an equal number of applications to screw/nail spots

### Step 5



Once fully set, use finishing materials for the last stages of jointing (see relevant product for finish coat application instructions)

#### Note:

This product has a working time of approx. 60 mins.

**Times and processes are given as guidance.  
On site practice may vary.**